

# Universal H-Series


## Troubleshooting Guide



# Table of Contents

|                               |             |                  |             |
|-------------------------------|-------------|------------------|-------------|
| Important Safety Instructions | Page 1      | BD Code          | Pages 30-31 |
| Sequence of Operation         | Pages 2-3   | EE and CE Codes  | Page 32     |
| Electric and Gas Connections  | Pages 4-5   | IO and SB Codes  | Page 33     |
| Control Hookup                | Pages 6-7   | SF and HS Codes  | Page 34     |
| Gas Pressure Testing          | Pages 8-9   | HE and PF Codes  | Page 35     |
| Control Board Connections     | Page 10     | HF Code          | Page 36     |
| Fuse Board Connections        | Page 11     | LO Code          | Pages 37-40 |
| Fuses                         | Page 12     | IF Code          | Pages 41-43 |
| Heater will not power up      | Pages 13-20 | AC Code          | Page 44     |
| Open FC1 and/or FC2 Fuse      | Pages 21-22 | AO Code          | Page 45-46  |
| Open FC3 and/or F1 Fuse       | Pages 23-26 | Flow Charts      | Pages 47-52 |
| Open FC4 Fuse                 | Pages 27-28 | Wiring Schematic | Page 53     |
| Diagnostic Codes              | Page 29     | Wiring Diagram   | Page 54     |

# Safety



**Warning**



## High Voltage Electrocution Hazard

Hazardous voltage can shock, burn, cause serious injury and or death. To reduce the risk of electrocution and or electric shock hazards:

- Only qualified technicians should attempt repairs.
- Replace damaged wiring immediately.
- Insure Heater is properly grounded and bonded.

# UHS Sequence Of Operation

The control continually compares the Set Temp to the actual water temp. When the water temp is 1° below the set point the sequence starts.

1. The control checks for open Blower Vacuum Switch
2. Blower starts pre-purge cycle as the igniter heats up (20 Sec).
3. The Control checks for a closed Blower Vacuum Switch.
4. At proper Igniter temp a 4 second trial begins. Gas valve opens and monitors flame sense. The blower will turn off for one second. The Igniter is de-energized at flame sense or at completion of 4 sec trial. If the flame is sensed, The Blower Vacuum Switch, Control Loop, Temp Sensor & Flame Sensor are constantly monitored during call for heat.
5. When set temp is reached, the control ends the call for heat. The gas valve is de-energized, flame is extinguished.
6. The blower will operate for a 30 second post purge.

# UHS Sequence Of Operation

## Failure to Light – Retry Sequence

1. Gas Valve de-energizes, 30 second blower post purge.
2. Starts over at #2 of heating mode sequence.
3. Retries 3 times until lockout (IF Code)
4. Waits 60 minutes then retries 3 more times
5. Will continue to retry every 60 minutes, until demand for heat is stopped.

**Note:** When making keypad entries of any type there may be a 5-10 sec delay for certain situations.

# UHS Electrical and Gas Connections

(Beginning Sept 08)


Located on both the left and right side of the heater cabinet.

Gas  
Supply

High  
Voltage

Bonding  
Lug

Low  
Voltage





# Electrical & Control Connections

(Beginning Sept 08)

120 VAC or 240  
VAC Connection

Ground




**Three Wire  
Remote  
Connection:**  
Orange (Pool),  
White (24V), and  
Red (Spa).


**Two Wire Remote  
Connection:** Orange  
(Pool) and White  
(Common)

# Control Hookup (Through August 08)

Control hookup located outside control box.



Two Wire Hook up:  
Orange (Pool) and White (24v)



Three Wire Hook up:  
Orange (Pool), White (24v), and Red (Spa)



# Control Configuration- Two wire

**Step 1:** Press the Mode button to place the heater in Standby Mode.

**Step 2:**

Hold the Mode and Down Arrow buttons simultaneously for 3 seconds for Bypass operation. “bo” will be displayed on the screen.

**Step 3:**

Heater must then be in Spa or Pool Mode for operation. The heater will fire when instructed by the external control.



**Note: 104° maximum temperature.**

# Gas Pressure Testing

## Step 1:

Measure the inlet Static Pressure (valve off) and Load Pressure (valve on / energized).



The Static and Load values should be within the levels listed on the Data Plate, example on **Page 9**.

## Step 2:

Measure the outlet Manifold Pressure (valve on / energized).



Manifold reading should be between 1.8"- 2.0" w.c for Natural or 6.8"- 7.0" w.c for Propane.


**Refer to Installation Manual for proper gas line sizing.**

# Gas Pressure Testing


## Step 3:

If inlet pressures are correct and the Manifold Pressure is low or high, adjust the Manifold Pressure at the Gas Valve.

Remove plug



Turn clockwise to increase pressure.



## Heater Data Plate

EQUIPPED WITH/ÉQUIPÉS DE  
**NATURAL GAS/GAZ**

POOL HEATER/Appareil DE CHAUFFAGE DE PISCINE  
ANSI Z21.56-2006 - CSA 4.7-2006

Manifold Gas Pressure/Pression de gaz au niveau du collecteur:  W.C./po c.d.'e

Orifices/Orifices de  Altitude  Feet/  p

Maximum inlet gas pressure/Pression de gaz maximale à l'admission:  W.C./po c.d.'e

Minimum inlet gas pressure/Pression de gaz minimale à l'admission:  W.C./po c.d.'e


Minimum thermal efficiency/Efficacité thermique minimale: 78%

Electrical rating/Alimentation électrique  volts, 1 ph. 60Hz  
less than 12 amps./less than 12 amperes

**Note: Never adjust valve if incoming pressure is not correct.**



# Integrated Control Board (ICB) Connections



# Fuse Circuit Board Connections

Power Connection  
for junction boxes.  
(after Aug 08)  
(P1)

Terminal block for  
field wiring  
connections. (TB1)  
(through Aug 08)


Configure heater  
for 240 VAC or 120  
VAC by installing  
correct plug. (P2)

Transformer  
Primary (P3)

Low Voltage  
(P5)

## High Voltage (P6)


Transformer  
Secondary (P4)





# Fuses

**FC1** and **FC2** fuses protect the primary input voltage. These fuses blow due to a shorted Fuse Board, shorted Transformer, improper or excessive voltage.



The **FC4** fuse protects the transformer (120VAC secondary output voltage) from a failed Blower, Igniter, or ICB.

The **FC3** fuse protects the transformer 24VAC secondary output voltage.


Situations that will cause this fuse to blow include:

- Short between FC3 to R & C on the ICB.
- Any short to ground at the E1 connector (external remote terminal) on the ICB or 24 VAC circuit.


# Troubleshooting: Heater will not power up

## Step 1:


Verify incoming voltage to heater is present (110-125 or 220-245 VAC), if voltage is present, proceed to **Step 2**. Otherwise, correct incoming line power to heater.



Models Prior to August 2008




Models After August 2008




# Troubleshooting: Heater will not power up

**Step 2:** Verify Voltage Selector Plug matches incoming line power.



**Step 3:** Inspect Fuse Board wiring and ensure all plugs are securely fastened to board.





# Troubleshooting: Heater will not power up

## Step 4:

Verify that FC1 and FC2 Fuses are not open. Check incoming voltage at bottom of both fuses (Fig. A) and out going voltage at top of both fuses (Fig. B), if no voltage present at top of both fuses, remove fuses from the Fuse Holders and measure continuity across each Fuse (Fig. C).



Fig. A




Fig. C




Fig. B






If Fuses are open, proceed to **Page 22**. Otherwise, reinstall the Fuses and continue to **Step 5**.

# Troubleshooting: Heater will not power up

## Step 5:

Disconnect plug from P4 connector from Fuse Board. Measure for 22-28 VAC between pins 1 & 2 of plug from Transformer and 110-125 VAC between pins 4 & 6.





If either voltage is incorrect, proceed to **Page 22**. Otherwise, proceed to **Step 6**.



# Troubleshooting: Heater will not power up



## Step 6:

Disconnect plug from P5 connector on Fuse Board and measure for low voltage (22-28 VAC) between R & C pins of P5 receptacle on Fuse Board. If voltage is not present, proceed to **Step 7**. Otherwise, proceed to **Step 8**.




## Step 7:

Measure for low voltage (22-28 VAC) between P5 C pin and bottom of FC3 fuse. If voltage is not present, replace Fuse Board. Otherwise, measure for low voltage between P5 C pin and top of FC3 fuse. If voltage is not present check for blown fuse. If fuse is blown proceed to **Page 12**, if voltage is present proceed to **Step 8**.



# Troubleshooting: Heater will not power up

**Step 8:** Inspect ICB wiring and ensure all plugs are securely fastened.






If wiring is OK and plugs are securely fastened, proceed to **Step 9**.



# Troubleshooting: Heater will not power up

**Step 9:** Verify low voltage (22-28 VAC) to ICB between R & C terminals.





If voltage is incorrect, replace the Wire Harness. If voltage is correct, proceed to **Step 10**.

# Troubleshooting: Heater will not power up


## Step 10:

Verify that F1 Fuse (3 AMP) on ICB is not open by measuring continuity across the Fuse. If fuse OK, proceed to **Step 11**. If fuse is blown, proceed to **page 24**.



## Step 11:


Verify 22 – 28 VAC is present between COM and AC terminals on ICB board. If voltage is present and display is blank, replace Display Board. If voltage is not present, replace ICB.



# Troubleshooting: Open FC1 and/or FC2 Fuses

## Step 1:

Verify that 120 VAC Voltage Selector Plug is NOT installed with a 240 VAC field power supply.




If correct plug is installed, proceed to **Step 2**. If incorrect, turn the power off and install the 240 VAC plug. Then replace FC1 and FC2 Fuses.



# Troubleshooting: Open FC1 and/or FC2 Fuses



## Step 2:

Check for faulty Transformer wiring and ensure the insulation on the wiring is not worn.



## Step 3:




Remove P4 and P3 plugs. Measure Transformer for resistance of 1.9 - 2.9 ohms between Black to Brown wires and between Orange to Yellow wires of P3.



If resistance is out of range, replace the Transformer.


# Troubleshooting: Open FC3 and/or F1 Fuse

**Step 1:** Check low voltage wiring / connections for worn insulation or pinched wiring.



# Troubleshooting: Open FC3 and/or F1 Fuses

**Step 2:** Inspect Gas Valve wiring and ensure insulation is not worn.




If wiring is OK, proceed to **Step 3**.



# Troubleshooting: Open FC3 and/or F1 Fuses

## Step 3:


Measure resistance across Gas Valve terminals (greater than .5 ohms) and between each terminal to Ground for short (there should be no continuity between either terminal to ground).



If a short exists (less than .5 ohms), replace the Gas Valve.  
Otherwise, proceed to **Step 4**.

# Troubleshooting: Open FC3 and/or F1 Fuses

**Step 4:** Check for faulty ICB wiring and ensure insulation on wiring is not worn.





If wiring is OK, replace the ICB.



# Troubleshooting: Open FC4 Fuse

## Step 1:

Inspect the Igniter and Blower Wiring and ensure the insulation is not worn.





If wiring is OK, proceed to **Step 2**. Otherwise, replace the defective component(s).

# Troubleshooting: Open FC4 Fuse

## Step 2:



Disconnect the Igniter Plug from the ICB and measure resistance across the Igniter. Resistance should be 10.9 – 19.7 ohms @ 77 degrees.



If resistance is out of range, replace the Igniter. If OK, proceed to **Step 3**.

## Step 3:

Disconnect the Blower Plug from ICB and measure the Blower resistance. Resistance should be 8-9 ohms from Black to Red wires and White to Blue wires.



If resistance is out of range, replace the Blower. Otherwise, proceed to **Page 30**.

# Diagnostic Codes

**Below is a list of all Diagnostic Codes for the UHS Heater.  
Troubleshooting Steps for each Code are covered on the following pages.**


| Diagnostic Code | Description  |
|-----------------|--|
| AC              | Blower Vacuum Switch closed  |
| AO              | Blower Vacuum Switch open  |
| BD              | Bad board or secondary high voltage fault                                      |
| CE              | Communication Error Between Control Module and Display Interface Assembly      |
| EE              | Bad board  |
| HE              | Rapid water temperature rise   |
| HF              | Flame present with Gas Valve not energized.                                    |
| HS              | Maximum return water temperature exceeded.                                     |
| IF              | Ignition Failure   |
| IO              | Igniter Failure  |
| LO              | Water Pressure Switch, Vent Pressure Switch, or Temperature Limit Switch Fault |
| PF              | Voltage polarity reversed, low voltage detected                                |
| SB              | Keypad failure   |
| SF              | Temperature Sensor (thermistor) input failure                                  |



# Service Light On: **BD Code**

**Step 1:**



**BD Code: Bad Board or Secondary High Voltage Fault.** Remove FC4 Fuse and measure continuity.



If Fuse is blown, go to **Page 27 (Open FC4 Fuse)**. If OK, proceed to **Step 2**.

**Step 2:**

Disconnect plug from P6 connector of Fuse Board and measure for 110-125 VAC across Pins 3 and 5 of P6 receptacle on Fuse Board.





If OK, proceed to **Step 3**. Otherwise, go to **Step 4**.

# Service Light On: **BD Code**

## Step 3:



Disconnect plug from E10 connector of ICB and measure for 110 -125 VAC across pins 1 and 3 of plug on Wire Harness.



If 110-125 VAC is present, replace the ICB. Otherwise, replace the Wire Harness.

## Step 4:


Disconnect plug from P4 connector of Fuse Board and measure for 110 -125 VAC between pins 4 and 6 of plug from Transformer.



If 110-125 VAC is present, replace the Fuse Board. Otherwise, replace the Transformer.

# Service Light On: **EE and CE Codes**




**EE Code:** “EEPROM Error” Defective ICB board. Replace ICB.



**CE Code:**

“**Communication Error**” between ICB and display board. Error may be cleared by cycling line power off and on. Otherwise, inspect Display Interface ribbon cable and ensure plug is securely attached to ICB.

**Display Board**





If Display Interface ribbon cable and connector plug is OK, replace the Display Interface Assembly. If code is still present, replace the ICB.



# Service Light On: **IO** and **SB** Codes

**IO Code:** **“Igniter Open”** Inspect Igniter wiring, ensure Igniter plug is securely attached to the ICB. Verify Igniter ohm resistance (10.9-19.7 Ohms).



If wiring damaged and/or ohms resistance is out of range, replace the Igniter.



**SB Code:** **“Stuck Button”** requires the Bezel/Keypad assembly to be replaced.



# Service Light On: **SF** and **HS** Codes

**Step 1:**

**SF Code: “Sensor Failure”** Inspect Temperature Sensor (thermistor) wire, make sure sensor is plugged into ICB securely.



**Step 2:**

Measure resistance between black wire and each red wire, the Temperature Sensor resistance should be the same (10k ohms at 77 degrees). If readings are significantly different from each other, replace the temperature sensor. Otherwise replace the ICB.

**HS Code:**

**“High Temperature Sense”** If water temperature exceeds 105° F the heater will shut down and go into lockout. Automatic restart is 2 minutes after water temp drops below 105° F.

# Service Light On: **HE and PF Codes**

## HE Code:

**“Heat Rise Excessive”** Inlet water temperature exceeds 5°F in a 5 second period. This is interpreted as a superheated water condition. If the control detects this condition 3 times, it will lock out and will require a power-cycle to reset.

## PF Code:

**“Polarity Failure”** This code will display if 120V polarity is reversed, low voltage is detected, or if the ground path is not sufficient. Reset is immediate after error is corrected.




# Service Light On: **HF Code**

## HF Code:

**“Heat or Flame Sensed”** Heat sensed when gas valve should be “OFF”. If flame is sensed with the gas valve off, the control will go into lockout. The blower will continuously run until error condition is corrected. When corrected, control will run blower for 5 seconds then automatically restart heater after 2 minutes.

Reset heater, cycle line power off and on.



If the code is still present, the Gas Valve is defective and needs to be replaced.

# Service Light On: **LO Code**

**Step 1:**

**LO Code: “Limit Open”** Verify pump is running and adequate water is flowing through heater. LO Code is normal when the pump is turned off.

**Step 2:**

Inspect Water Pressure Switch wiring and ensure Wire Harness terminals are securely fastened to the spade terminals on the Water Pressure Switch.



**Step 3:**

Remove wires from Water Pressure Switch and measure continuity across the terminals while pump is running. If open, replace Pressure Switch. Otherwise, go to **Step 4**.



# Service Light On: **LO Code**


## Step 4:

Certain applications will require the adjustment of the Pressure Switch, refer to section of the installation/service manual **Water Pressure Switch Test / Adjustment Procedures.**



## Step 5:


Inspect Temperature Limit Switch Wiring and ensure wire harness terminals are securely fastened.





# Service Light On: LO Code

**Step 6:** Measure continuity across the Temperature Limit Switches.



If open, replace the Temperature Limit Switch(s).

## **Applies Only To Indoor Installations**

**Step 7:** Inspect the Vent Pressure Switch Wiring and Hose connections. Ensure Wire Harness is securely fastened and tubing is attached to Blower and Vent Pressure Switch.



If OK, proceed to **Step 8**.

# Service Light On: LO Code

## Applies Only To Indoor Installations

**Step 7:** Ensure that flue is not blocked or restricted. See indoor vent sizing requirements in Installation Manual.


**Step 8:** Remove wires from Vent Pressure Switch and measure continuity between terminals. While heater is running, measure continuity across the Vent Pressure Switch.






If open, replace Vent Pressure Switch.

# Service Light On: **IF Code**

**Step 1:** IF “Ignition Failure” Ensure main gas shutoff outside the heater is open and that the Gas Valve inside the heater is in the “ON” position.



**Step 2:** Inspect Flame Sensor and Gas Valve wiring and ensure wire harness is securely fastened to the terminals.



**Step 3:** Ensure Gas Static, Load and Manifold pressures are correct. See **Page 8**.

If OK, proceed to **Step 5**, Otherwise proceed to **Step 4**



# Service Light On: IF Code

**Step 4:** Measure for 22-28 VAC across Gas Valve during trial for ignition.



If 22-28 VAC is present and Gas Valve does not open with manometer connected to valve, replace Gas Valve. See **Page 8** for reference. If 22-28 VAC is not present, replace the ICB.

**Step 5:**


**For models manufactured prior to 4/14/2009**

Verify which flame sensor is installed. If 3" flame sensor installed, replace to 5" flame sensor. **Part # IDXLFLS1930**



# Service Light On: IF Code

**Step 6:** Remove and inspect Gas Orifices and Burners for blockage.




**NOTE:** Check for excessive moisture in combustion chamber.  
Determine possible causes; roof run-off, sprinklers, etc..


# Service Light On: **AC Code**

## Step 1:

**AC Code: “Air Switch Closed”** Blower vacuum switch closed when expected open. Disconnect wires and tubing from switch, measure continuity between terminals on switch, if continuity exist, replace switch.





**Step 2:** With heater off, If blower continues to run, replace ICB.






# Service Light On: **AO Code**

**Step 1:** Check for faulty Blower and Blower Vacuum Switch Wiring, Tubing, and Connections.





**Step 2:** Ensure Voltage Selector Plug is configured for correct field supplied voltage.



# Service Light On: **AO Code**

## Step 3:



Disconnect Blower Plug from ICB and measure resistance across Blower windings for 8 to 9 ohms from Black to Red Wires and White to Blue Wires.



If resistance is out of range, replace the Blower. If OK, proceed to **Step 4**.


## Step 4:

Disconnect Blower Plug from ICB and generate a call for heat. While in pre-purge, measure for 110-125 VAC across Pins 1 & 2 of inducer on ICB.




If 110-125 VAC is not present, replace the ICB. If 110-125 VAC is present and Blower is running, replace the Blower Vacuum Switch.

# Flow Chart - Heater will not power up







# Flow Chart- Blown FC1 and/or FC2 Fuse




# Flow Chart- Blown FC3 and/or F1 Fuse




# Flow Chart- **BD Code**



# Flow Chart- LO Code




# Flow Chart - IF Code






# Flow Chart - AO & AC Code



# Schematic



# Wiring Connection Diagram

